Opus aeroPOUCH 3

PL Instrukcja obsługi

1 ZASADY BEZPIECZEŃSTWA

- Umieść urządzenie w pobliżu gniazdka elektrycznego.
- Upewnij się, że napięcie odpowiada wymaganiom elektrycznym urządzenia.
- Nie uruchamiaj urządzenia, jeśli przewód zasilający jest uszkodzony.
- Wszystkie naprawy powinny być wykonane przez autoryzowany serwis.

2 ZASADY BEZPIECZEŃSTWA

Przed użyciem urządzenia przeczytaj uważnie instrukcję obsługi.

- Ostrożnie wyjmij urządzenie z opakowania.
- Umieść urządzenie na czystym i płaskim stole roboczym, patrz rysunek A.
- Upewnij się, że otwory wentylacyjne nie są przysłonięte rys.1
- Należy wyczyścić wlot aby uniknąć przedostania się pyłu do urządzenia.

A

3 OPIS URZĄDZENIA

A. Przewód zasilający
B. Włącznik zasilania
C. Wałek podający
D. Kolumny napinające
E. Rolka dociskowa
F. Wyłącznik rolki
G. Dysza powietrza
H. Wałek grzewczy
I. Rolki wyciągające
J. Przycisk Start / Stop ▶
K. Wskaźnik zasilania (wskaźnik czerwony)
L. Wskaźnik ciśnienia powietrza (wskaźnik zielony)
M. Redukcja ciśnienia powietrza (–)
N. Zwiększenie ciśnienia powietrza (+)

4 INSTALACJA

- Zamontuj rolkę z folią.
- Folię należy przeciąć nożyczkami w prawym dolnym rogu przed umieszczeniem jej w urządzeniu, rys. B.
- Prawidłowo umieść rolkę folii na wałku podającym. Wałek posiada wystającą prowadnicę, która powinna pokryć się z wycięciem wewnątrz rolki folii rys. 3.
- Zwróć uwagę na kierunek nałożenia folii na kolumny napinające patrz rys. 4
- Odblokuj rolkę i przeprowadź przez nią folię. Gdy folia przesuwa się prawidłowo zablokuj rolkę rys. 5.
- Przeprowadź folię przez dyszę powietrzną rys. 6.
- Upewnij się, że folia znajduje się dokładnie pomiędzy wałkami zgrzewającymi tak aby po włączeniu przycisku Start / Stop rozpocząć płynne zgrzewanie rys. 7, 8.

5 OBSŁUGA

- Podłącz przewód zasilający i włącz zasilanie rys.9.
- Zapali się czerwona lampka wskaźnika zasilania i zacznie migać zielona lampka, urządzenie jest w trakcie nagrzewania (czas nagrzewania około 4 min).
- Gdy wskaźnik ciśnienia (zielona lampka) zaświeci się na stałe urządzenie jest gotowe do pracy.
- Naciśnij przycisk Start / Stop, aby rozpocząć tworzenie poduszki powietrznej.
- Po zakończeniu tworzenia poduszki powietrznej naciśnij ponownie przycisk Start / Stop, urządzenie się zatrzyma. Na folii znajduje się linia perforacji, aby oderwać niezbędną długość zgodnie z wymaganiami. Jeżeli nie ma konieczności wymiany folii oderwij kawałek zgodnie z wymaganiami. Jeżeli jest konieczność wymiany folii oderwij ją przed wałkami grzewczymi.
- Ustawienie ilości powietrza: dostępne są różne rozmiary poduszek, aby spełnić różne wymagania dotyczące pakowania. Należy użyć przycisku +/- regulacji ciśnienia, aby ustawić ilość powietrza zgodnie z zapotrzebowaniem. Ustaw odpowiednie ciśnienie powietrza, aby uzyskać najlepszą wydajność poduszki powietrznej. Zbyt duże ciśnienie powietrza spowoduje zacięcie lub złe działanie poduszki powietrznej (Uwaga: trzy poziomy z lewej strony są sugerowane dla folii o szerokości 200 mm, trzy poziomy z prawej strony dla folii o szerokości 400 mm) rys. 10.
- W przypadku ciągłej pracy urządzenia, nie zatrzymuj go przyciskiem Start / Stop na dłużej niż 30 sekund gdyż może dojść do stopienia foli. Taka sytuacja nie wpływa na

jakość zgrzewania jednak w przypadku dłuższej przerwy zalecamy wyciągnięcie foli spod gorących wałków.

- Aby wyłączyć urządzenie naciśnij przycisk Start / Stop oderwij folię na linii perforacji przed dyszą powietrzną, włącz urządzenie ponownie przyciskiem Start / Stop, aby usunąć resztkę foli. Ponownie naciśnij przycisk Start / Stop aby zatrzymać urządzenie. W tym momencie możesz wyłączyć urządzenie przyciskiem zasilania.
- Jeżeli urządzenie zostało wyłączone i ponownie włączone w ciągu 30 sekund należy przycisnąć obydwa przyciski regulacji ilości powietrza przez 4 sekundy. Następnie należy zaczekać na zielony wskaźnik zasilania (urządzenie nagrzeje się w czasie krótszym niż 4 minuty).
- Funkcja hibernacji. Po 30 minutach bezczynności urządzenie przejdzie w stan hibernacji. Każde ponowne naciśnięcie przycisku Start / Stop powoduje zresetowanie odliczania do hibernacji. Podczas stanu hibernacji, czerwona dioda zasilania miga, zielone światło Start / Stop gaśnie, a silnik, dmuchawa powietrza i system ogrzewania przestają działać. Ponowne naciśnięcie przycisku Start / Stop spowoduje wybudzenie urządzenia, zaświeci się czerwona lampka, zielona lampka miga. Po 4 minutach nagrzewania, zielona lampka zaświeci się na stałe, naciśnij przycisk Start / Stop, aby normalnie korzystać z urządzenia.
- Uwaga: urządzenie musi się rozgrzać przez około 4 minuty w przypadku bardzo zimnego rozruchu. Sugerujemy montaż folii zaraz po włączeniu zasilania.

6 WYMIANA NOŻA

Etapy wymiany noża z dyszą powietrzną.

- Za pomocą śrubokręta odkręć śruby mocujące dyszę powietrza rys. 11 A.
- Wyciągnij dyszę powietrzą rys. 11B.
- Odkręć śruby mocujące nóż rys. 12.
- Wymień nóż na nowy (Uwaga: uważaj na ostrze, którym można się skaleczyć).
- Załóż z powrotem dyszę powietrza i mocno dokręć śrubokrętem 2 śruby mocujące. rys. 11, 12
- Uwaga: Aby nóż prawidłowo przecinał folie należy go wymieniać regularnie zwłaszcza podczas intensywnego użytkowania.

7 KONSERWACJA

- Odłącz przewód zasilający podczas konserwacji.
- Regularnie czyść elementy grzejne rys.13.
- Upewnij się, że nie ma zakleszczonej folii i brudu na dyszy powietrza lub ostrzu noża.
- Regularnie czyść dyszę powietrza.
- Wymień ostrze, gdy jest stępione.

8 SPECYFIKACJA

- Prędkość zgrzewania: ..... 3 m/min ±10% (prędkość stała)
- Kontrola przepływu powietrza: ..... Regulacja (200 / 400 mm w różnym zakresie ustawień i pracy)
- Wymiary folii: ..... 200 x 80 mm, 200 x 100 mm, 200 x 150 mm
  200 x 200 mm,400 x 250 mm, 400 x 290 mm
- Zasilanie: ..... AC 220–240 V 50 Hz
  AC 110–120 V 60 Hz
- Moc znamionowa: ..... 160 W
- Maksymalny pobór prądu: ..... 2,5 A
- Wymiary (W x S x G): ..... 209 x 475 x 220 mm
- Waga netto: ..... 3,7 kg
- Waga brutto: ..... 4,7 kg

Zużyty sprzęt oznakowany niniejszym symbolem nie może być umieszczany i usuwany łącznie z innymi odpadami, w tym odpadami komunalnymi. Obowiązkiem użytkownika jest przekazanie zużytego produktu do punktu zbiórki w celu recyklingu odpadów powstałych ze sprzętu elektrycznego i elektronicznego. Właściwa segregacja i selektywna zbiórka odpadów zużytego sprzętu zmniejsza negatywne oddziaływanie substancji niebezpiecznych, które mogą się w nim znajdować, na środowisko naturalne i zdrowie człowieka. W celu uzyskania bardziej szczegółowych informacji dotyczących utylizacji zużytego sprzętu prosimy skontaktować się z przedstawicielem władz lokalnych, dostawcą usług utylizacji odpadów lub punktem sprzedaży, gdzie nabyto produkt. Zapewniając prawidłową utylizację sprzętu pomagamy chronić środowisko naturalne.

Opus aeroPOUCH 3

EN User guide

1 HEALTH AND SAFETY PRECAUTIONSA

- Place the equipment close to a power socket of the correct voltage.
- Ensure the voltage is the same as in the manual and the label on the equipment.
- Do not use the power cable if it is damaged.
- Repair and service should be carried out by OPUS qualified service technicians during the guarantee period.

2 UNPACKING

Please read carefully before use.

- Remove the equipment from the packing box carefully.
- Put the equipment on a clean, stable and flat surface. Diagram A.
- Ensure the air blower vent on the bottom is not blocked, see Dig 1 below.
- Make sure that the area around the INLET vent on the bottom of the unit is dust and dirt free to avoid damage to the air blower system.

DIG A

3 DEVICE DESCRIPTION

A. Power cable
B. Power Switch
C. Feeder drive capstan
D. Tension guide bars
E. Foil tension roller
F. Foil tension roller release / lock switch
G. Foil bag inflator air tube and nozzle
H. Heated sealing rollers
I. Foil Puller wheels
J. Start / Stop button
K. Power on Indicator(Red LED)
L. Air pressure Indicator(Green LED)
M.Reduce air flow (-)
N. Increase air flow (+)

4 INSTALLATION

- Before you install the roll of foil cut the lower corner off with a pair of Sharp scissors. See (Dig.B) Below.
- Put the roll foil on the feeder capstan carefully, there are grooves inside the roll that line up with the feeder capstan. See Dig 3 (C) below.
- Unlock the foil tension roller Dig 5 (E)
- Now feed the foil through to the tension guide bars as seen in Dig 4 (D) below.
- After the foil has passed through the tension guide bars and between the tension roller, now lock the roller on to the foil as seen in Dig 5 (F) lock position.
- Now feed the foil onto the nozzle and tube up to the sealing rollers, see Dig 6 (G)
- Pull the foil up to the hot sealing rollers so it can grip the foil. Hold the foil with one hand to guide it through, then push the start button helping the foil to start pulling the foil through rollers.
- Now the air cushions will run smoothly. See Dig 7& 8.

DIG B

5 OPERATIONS

- Plug in the equipment to the power socket.
- On the display panel, a red for 'power' and a green blinking light comes on. The green light will stop blinking when the correct temperature for sealing the bags is reached.
- Press Start / Stop button to start making air bags.
- When you have finished making air bags, press the Start / Stop button again and it will stop making the bags immediately. There is a perforated line on the foil between the bags so you can tear off the necessary length needed for packing your goods. You do not need to remove the roll of foil, just tear off the foil bags at the sealing rollers ready to use again; When fitting a new roll of foil air bags remove the empty roll from the capstan (C) and follow the same the procedure as above.
- Air density/flow setting: Various cushion sizes are available to meet different packing requirements. The user can adjust the air density/flow to meet the sizes. Too much air pressure or when there is not enough air will course a blockage.
- For foil bags with a width of 200 mm try up 3 green LEDS. For bags with a width of 400 mm try from 4 up to 6 green LEDS. See Dig 10. Next page.
- If continuous use the equipment, press the Start / Stop button when equipment indicator

are not blinking, and you pause for more than 30 seconds it may cause foil within the hot rollers to melt and break. This is a normal condition as the hot roller always in a constant heating process.

- If you want to turn off the power, please make sure power indicator is not blinking, tear off the foil bags on the perforated after the air nozzle tube, and press Start / Stop button to eject the foil bags completed, then press the Start / Stop button again to stop the operation, then you can turn off the power by the switch.
- If you switch off the equipment and decide to use again within 30 seconds, press the plus and minus keys on the air control panel at the same time for 4 seconds, then wait until the power and green led's stop blinking. For this condition, the warm up time is less than 4 minutes.
- Standby function, after continues non-use of 30 minutes, equipment will go into a standby status. Each standby countdown is trigged by pressing Start / Stop button, which will reset the count down cycle. During the standby status, the power indicate red-light goes to a slow blink, the green led goes off and the motor, air blower, and heating system all stop working. By pressing Start / Stop button again, it will wake up the equipment, the red led goes on, green led blinks. After 4 minutes warm up time or when the green led stops blinking, press Start / Stop button to use the equipment normally.
- Caution: The equipment needs to warm up for round 4 minutes for every cold start. We suggest installing the roll foil bags after turning on the power switch.

6 CUTTER REPLACEMENT

- Cutting blade replacement on the air nozzle tube.
- Use a Philips/crosshead screw driver to remove the air nozzle tube assembly screws. Dig 11(A).
- Pulling out the air nozzle tube assembly. Dig 11(B).
- Remove the screw from the blade. Dig12.
- Renew the cutting blade and replace the screw firmly. (CAUTION:SHARP BLAD IT COULD CUT YOUR FINGERS).
- Refit the air nozzle tube assembly with new blade with the 2 screws and fit firmly. See Dig. 11&12.

Caution:

- Renewed the cutting blade often, this will ensure the foil bags run through smoothly and properly made.

7 MAINTENANCE

- Unplug the power cable during maintenance.
- Clean the hot sealing rollers regularly. Dig 13. (H&I).
- Ensure there is no foil stuck or jammed on or in the roller mechanism and there is on dirty or dust around the air inlet vent.
- Clean the air nozzle tube assembly and cutting blade regularly.
- Renew the cutter blade regularly.

8 SPECIFICATION

- Sealing speed: ..... 3 m/min +/- 10 % (Fix speed)
- Adjustable air flow control: ..... for 200 or 400 mm foil bags
- Foil bag roll sizes:. ..... 200 x 80 mm, 200 x 100 mm, 200 x 150 mm
  200 x 200 mm,400 x 250 mm, 400 x 290 mm
- Power voltage: ..... AC 220-240 V 50 Hz
  AC 110-120 V 60 Hz
- Electrical power rate: ..... .160 Watts
- Rated power:. ..... .2.5 Amps
- Dimension: ..... .H: 209 x W: 475 x D: 220 mm
- Net weight: ..... .3.7 kg
- Gross weight: ..... .4.7 kg

Equipment and products marked with this symbol cannot be deposed together with normal or municipal waste. The user is required to take their used product to a collection point for recycling of waste electrical and electronic equipment. Proper segregation of used equipment reduces the negative impact of hazardous substances that may be in there, in to the environment which could impact, human and wild life health. For more detailed information concerning the disposal of used equipment, please contact your local authority, waste disposal service or the point of sale where you purchased the product. By ensuring proper disposal of equipment we are helping to protect the environment, humanity and wild life health.